## - MK66 Pro Manual -

## **Hotkeys:**

Knob: Volume control/Press down to mute

Volume control ress down to

FN + Up/Down arrow: Backlight +/-

FN + Right/Left arrow: Backlight speed +/-

FN + Esc = ~

FN + Win = Win lock

FN + 1 - -+ = F1-F12

FN + | = RGB changing

FN + P = Color change

FN + Backspace = RGB On/Off

FN + Q/W/E = Bluetooth 1/2/3

FN + R = 2.4G

FN + T = Wired connection

FN + Alt + Space = Energy saving mode

(long press 3s)

FN + U = Print

FN + J = Insert

FN + Pg Dn = Del

FN + A = Play/Stop

FN + I = Scroll

FN + K = Home

FN + S = Prev Media

FN + O = Pause

FN + L = End

FN + D = Next Media

FN + Alt = Win/Mac mode (long press 3s) Ctrl + Alt + Q: RESET (long press 3s)

Backlight Mode: Normal light mode can not adjust the backlight speed;

the rest of the backlight mode can adjust the speed, brightness, color, direction.

Brightness in five levels, default maximum brightness;

speed in five levels, default third level speed.

## **Battery indicator**: Lithium battery (3.7V):

The battery voltage is lower than 3.3V, Ctrl key indicator light flashes red when battery is low; green for charging status; returns to normal backlight means fully charged.

## 2.4G/Bluetooth/Wired Pairing/Software:

2.4G Paring: After the keyboard is turned on, press Fn+R to enter 2.4G mode.
At this time, the R key flashes slowly, long press Fn+R combination key for 3s to enter pairing mode. The R key light flashes quickly, plug the receiver now.
After pairing success, the R key will stop flashing. After 30 seconds not finding the paired device, exit pairing mode indicator will turn off, keyboard go back to sleep.
(Since 2.4g communication is easily affected by wifi and bluetooth frequency, if connection failed for the first time, try to temporarily turn off the wifi and bluetooth at home, reset the keyboard, then continue to connect. Once the connection is successful, it will basically not failed again)

Bluetooth Paring: After the keyboard is turned on, press Fn+Q/W/E key combination to enter Bluetooth mode, long press Fn+Q/W/E key combination for 3s, the keyboard enters pairing state, indicator light flashes quickly, and the device indicator light will light up for 2 seconds. The device not connected light goes off and the keyboard goes to sleep.

Wired connection: Long press Fn+T to pair.

Software connection: Plug in wire to use software, activate wired mode by Fn+T

http://www.mathewkb.com