
NK98T

3-Mode RGB Mechanical Keyboard

<http://www.mathewkb.com>

Version:2.0


2022/12/08

By:MATHEW


Charging Indication

When the battery is low, the right Ctrl key keeps flashing red quickly until the keyboard is turned off. When plugging in the Type-c cable to charge, the right Ctrl key will be solid red for 3 seconds and then synchronized with the backlight.

Note*: Do not expose the battery of this product to the sun, and the input voltage is limited to 5V (overvoltage may cause damage to the product and cannot enjoy warranty service).




Indicator Light/Knob




	NUM indicator: Lights up when the NUM key is pressed.		Caps indicator: Lights up when caps is on.		WIN key lock indicator: Press FN+WIN, the indicator light is on, the WIN key is locked.		Press FN+S to enter the MAC system, the three indicator lights flash 5 times at the same time to prompt.
--	---	--	--	--	---	--	---

Three-stage Switch



Three-stage gear switch, when using different ways to connect the keyboard, turn the switch to the corresponding gear.

Bluetooth/2.4G Connection/Wired Connection




1. Bluetooth device switching: Turn the bottom switch to the B position, short press FN+Q/W/E to switch the device 1.2.3, the corresponding backlight flashes 3 times to indicate.
For example: Code pairing the Bluetooth device 1 is to press and hold FN+Q for 3 seconds, the Q backlight blue light flashes quickly. After the code pairing is successful, the light is synchronized with the backlight.
2. Code pairing 2.4G: Turn the bottom switch to the G position, press and hold the FN+R key for 3 seconds, and the backlight flashes green rapidly. Insert the receiver into the PC, after the code is successfully paired, the light and the backlight are synchronized.
3. Wired connection: Turn the bottom switch to the U position, insert the type-c interface of the data cable into the keyboard interface, and insert the USB interface into the computer interface.

Keyboard Backlight Recording Method

Backlight record key combination



Backlight recording mode steps

















FN Key Combination

WIN system shortcut keys

FN + A	Enter WIN system	FN + O	HOME	FN + I	END
FN + F1	Screen brightness-	FN + F5	Keyboard backlight brightness-	FN + F9	Next track
FN + F2	Screen brightness+	FN + F6	Keyboard backlight brightness+	FN + F10	Mute
FN + F3	Multitasking windows	FN + F7	Previous	FN + F11	Volume-
FN + F4	Program list	FN + F8	Pause/Play	FN + F12	Volume+
FN + Y	Scroll lock	FN + U	PAUSE BREAK		













Note: Only computers that support shortcut key brightness adjustment in the Windows system can adjust the screen brightness.

MAC system shortcut keys

	+		Enter MAC system (the WIN key and the ALT key are interchanged)
			Screen brightness-
			Keyboard backlight brightness-
			Next track
			Screen brightness+
			Keyboard backlight brightness+
			Mute
			Multitasking windows
			Previous
			Volume-
			Program list
			Pause/Play
			Volume+

Note: FN+(F1-F12) in MAC system corresponds to F1-F12 keys, directly press F1-F12 corresponding to multimedia functions in MAC system.

Backlight shortcut keys

	+		Backlight mode switching
	+		Turn off/on backlight
	+		Backlight speed+
	+		Dynamic backlight direction switching
	+		Backlight speed-
	+		Backlight monochrome switching (monochrome keyboard without this function)

Special shortcut keys

	+		Press and hold for 3 seconds to restore factory settings
	+		Display wireless pairing channel